



TOP VIEW




ASSEMBLY PROCEDURE:

- 1) PLACE THE DRIP SHIELD (ITEM 1) AS SHOWN ON TOP OF YOUR STYLE-5017 BATTERY CHARGER ENCLOSURE. NOTICE THE NOTCHES ON THE SHIELD ARE FACING THE REAR OF THE CABINET.
- 2) ALIGN THE TWO (2) SETS OF CENTER SLOTS ON THE DRIP SHIELD WITH THE PRE-PUNCHED HOLES ON THE STYLE-5017 CHARGER ENCLOSURE.
- 3) SECURE THE DRIP SHIELD TO THE ENCLOSURE BY USING THE SUPPLIED 0.25-20 x 0.625in SELF-CUTTING SCREWS (ITEM 2) AS SHOWN.


ITEM #1



FRONT VIEW



ITEM #2 SIDE VIEW



NOTES:

- 1) BASE ENCLOSURE IS A NEMA-1 / IP20 TYPE STEEL CABINET WITHOUT GASKETS, FINISH IS ANSI-61 GRAY EPOXY POWDERCOAT.
- 2) ALLOW 6in / 152mm OF FREE AIR ON TOP, SIDES, AND FRONT OF CABINET FOR VENTILATION.
- 3) SEE DRAWING (JE5025-00) FOR SPECIFICATIONS OF STANDARD NEMA-1 STYLE-5017 ENCLOSURE.
<http://www.ATSeries.net/PDFs/JE5025-00.pdf>
- 4) WITH DRIP SHIELD INSTALLED, BATTERY CHARGER ASSEMBLY MEETS NEMA-2 / IP30 STANDARDS.

DUAL DIMENSIONS in mm

			THIRD ANGLE PROJECTION					
			DRAWN BY MCR 112410 ELECTRONIC APPROVAL SIGNATURES MAINTAINED BY MFG ECN LOG	TITLE CUSTOMER INSTALLATION INSTRUCTIONS AT10.1 GRP II DRIP SHIELD ACSY: EI0191-01				
A	N/A	112410	UNLESS OTHERWISE NOTED DIMENSIONS ARE IN INCHES. TOLERANCES ARE:		DRAWING No JA0092-01		REV A	B
REV	ECN No	DATE	SCALE	NTS	PART No	JA0092-01	SHEET	1 OF 1